

PG-Flex^{Plus}

RPOTS 6 Channel

Remote Terminal Channel Unit

Technical Practice



| Model | List | CLEI Code |
|---------|------|------------|
| FPR-806 | 1 | S9C2BB0B~~ |

REVISION HISTORY

| Revision | Release Date | Revisions Made |
|----------|----------------|-----------------|
| 01 | March 24, 2003 | Initial Release |

Copyright © 2003 ADC DSL Systems, Inc. All Rights Reserved.

ADC is a registered trademark of ADC Telecommunications, Inc. PG-Flex^{Plus} is a trademark of ADC DSL Systems, Inc. No right, license, or interest to such trademarks is granted hereunder, and you agree that you shall assert no such right, license, or interest with respect to such trademarks.

Other product names mentioned in this document are used for identification purposes only and may be trademarks or registered trademarks of their respective companies.






Information contained in this document is company private to ADC DSL Systems, Inc., and shall not be modified, used, copied, reproduced or disclosed in whole or in part without the written consent of ADC.

Contents herein are current as of the date of publication. ADC reserves the right to change specifications at any time without notice. Information furnished by ADC is believed to be accurate and reliable. In no event shall ADC be liable for any damages resulting from the loss of data, loss of use, or loss of profits and ADC further disclaims any and all liability for indirect, incidental, special, consequential or other similar damages. This disclaimer of liability applies to all products, publications and services during and after the warranty period.

USING THIS TECHNICAL PRACTICE

The following style conventions and terminology are used throughout this guide.

| Element | Meaning |
|----------------|--|
| Bold font | Text that you must input exactly as shown (e.g., type 1 for card 1), menu buttons (e.g., ACCEPT SHELF OPTIONS) or menu screen options (e.g., ALARMS screen) that you must select |
| Italic font | Variables that you must determine before inputting the correct value (e.g., <i>Password</i>) |
| Monospace font | References to screen prompts (e.g., Invalid Password...Try Again..) |

| Reader Alert | Meaning |
|---|---|
|  | Alerts you to supplementary information |
| IMPORTANT  | Alerts you to supplementary information that is essential to the completion of a task |
|  | Alerts you to possible equipment damage from electrostatic discharge |
| CAUTION | Alerts you to possible data loss, service-affecting procedures, or other similar type problems |
|  | Alerts you that failure to take or avoid a specific action might result in hardware damage or loss of service |
|  | Alerts you that failure to take or avoid a specific action might result in personal harm |

INSPECTING YOUR SHIPMENT

Upon receipt of the equipment:

- Unpack each container and visually inspect the contents for signs of damage. If the equipment has been damaged in transit, immediately report the extent of damage to the transportation company and to ADC. Order replacement equipment, if necessary.
- Check the packing list to ensure complete and accurate shipment of each listed item. If the shipment is short or irregular, contact ADC as described in [Product Support on page 45](#). If you must store the equipment for a prolonged period, store the equipment in its original container.

Table of Contents

| | |
|--|----|
| Revision History | i |
| Using this Technical Practice | ii |
| Inspecting Your Shipment | ii |
| Overview | 1 |
| Features | 1 |
| Applications | 1 |
| Integrated Distributed DLC | 1 |
| Universal Distributed DLC | 2 |
| System Support for DID | 3 |
| System Configurations supporting the FPR-806 | 4 |
| Subscriber Drop Tests | 5 |
| Specifications | 6 |
| Front Panel | 7 |
| Installation and Test | 9 |
| Required Tools and Test Equipment | 9 |
| Installation | 9 |
| Install an FPR-806 | 9 |
| Initialize and Power Up the FPR-806 | 9 |
| Administration | 9 |
| Navigational Methods | 10 |
| Provisioning, Testing and Maintenance | 11 |
| Menus and Display Structure | 11 |
| Log On the FPR-806 Through the Management Unit (AMU-912) | 12 |
| Logout | 15 |
| Main Menu Options | 17 |
| MAIN | 18 |
| Alarm Menu Options | 19 |
| ALARMS — System History | 20 |
| Configuration Menu Options | 23 |
| CONFIG — System Options | 24 |
| CONFIG — System Alarm Types | 27 |
| CONFIG — Set Factory Defaults | 30 |
| TEST — Subscriber Drop Test | 33 |
| Information Menu Options | 35 |
| INFO — Inventory | 36 |

| | |
|----------------------------------|----|
| INFO — Event Log | 37 |
| INFO — Help | 39 |
| Subscriber Reported Faults | 41 |
| Acronyms | 43 |
| Product Support | 45 |
| Technical Support | 45 |
| Limited Warranty | 45 |
| Returns | 45 |
| FCC Class A Compliance | 46 |
| Modifications | 46 |

List of Figures

| | | |
|-----------|---|----|
| Figure 1. | Integrated Distributed DLC | 1 |
| Figure 2. | Universal Distributed DLC | 2 |
| Figure 3. | System Support for DID | 3 |
| Figure 4. | FPR-806 Front Panel | 7 |
| Figure 5. | Terminal Menu and Display Structure | 11 |

List of Tables

| | | |
|-----------|--|----|
| Table 1. | System Supported Shelf and Card Configurations | 4 |
| Table 2. | DC Resistive Signatures | 5 |
| Table 3. | Specifications | 6 |
| Table 4. | FPR-806 Front Panel LEDs | 8 |
| Table 5. | FPR-806 Diagnostic Indicators | 8 |
| Table 6. | Navigational Keystrokes | 10 |
| Table 7. | Alarm Menu Options | 19 |
| Table 8. | Configuration Menu Options | 23 |
| Table 9. | Shelf Options | 26 |
| Table 10. | Alarm Types Reported | 29 |
| Table 11. | Alarm Types | 29 |
| Table 12. | Test Menu Options | 32 |
| Table 13. | Information Menu Options | 35 |
| Table 14. | Fault Isolation and Troubleshooting | 40 |
| Table 15. | Subscriber Fault Isolating | 41 |

OVERVIEW

The FPR-806 Remote Channel Unit Module RPOTS card provides the Remote Terminal (RT) Plain Old Telephone Service (POTS) function in the PG-Flex^{Plus} distributed DLC platform.

FEATURES

Features supported by the FPR-806 include:

- Six Remote Terminal POTS interfaces
- Loop Start/Ground Start (LS/GS) and Direct Inward Dialing (DID) services
- MLT and Subscriber Drop Testing support

APPLICATIONS

When used in conjunction with the supported system configurations, the FPR-806 enables the system to deliver POTS directly at the DLC remote location in the following applications:

- Integrated Distributed DLC
- Universal Distributed DLC
- System Support for DID

Integrated Distributed DLC

As a distributed Integrated DLC (Figure 1), the remote system shelf can be placed in a CO, CEV or outdoor cabinet; anywhere that the DS1 facility can be delivered and subtended directly off the switch. The system supports TR-08 Mode 1 or SF/ESF Integrated Channel Bank (ICB) interfaces into digital class 5 switches. The 96 channels delivered to the system Remote shelf can be directly dropped off at the shelf via the FPR-806 or delivered to distributed, line-powered, micro-DLC remotes ranging from four to twenty-four channels in size.




Figure 1. Integrated Distributed DLC

Universal Distributed DLC

The system can also be deployed in a universal configuration using POTS interfaces into the switch rather than digital DS1s (Figure 2). In this configuration, a system shelf populated with FPC-806 CPOTS cards is placed in the CO to provide the VF interface into the class 5 switch. As a distributed, universally fed DLC, the remote system shelf can be placed in a CO, CEV or outdoor cabinet; anywhere that the DS1 facility can be delivered.




Figure 2. Universal Distributed DLC

When operating in an universal mode, back-to-back with a CO shelf, the remote shelf communicates the drop testing results through overhead communications to the CO shelf where the MLT reads the TR-909 signatures from the CO shelf.



Using the overhead communications in the universal configuration allows the system to support drop testing without the need for a metallic bypass pair to the remote shelf.

The 96 channels delivered to the system Remote shelf can be directly dropped off at the shelf via the FPR-806 or delivered to subtended line-powered, micro-DLC remotes ranging from four to 24 channels in size.

System Support for DID

The system supports DID to a Private Branch eXchange (PBX) (Figure 3). DID can be served in a universal system configuration where the DID lines enter the CO shelf through FPR-806 cards and the PBX interfaces to the remote system shelf through the FPC-806 cards.




Figure 3. System Support for DID

System Configurations supporting the FPR-806

Table 1 summarizes the supported cards for a system configuration in which the FPR-806 is used to deliver POTS directly at the DLC remote site.

Table 1. System Supported Shelf and Card Configurations

| Catalog Number | Description | Notes |
|---|---|--------------|
| PG-Flex^{Plus} Shelf | | |
| PCS-719 L1A | 23" Shelf | 1 |
| PCS-719 L3 | 23" Shelf with DS3 UNI Support | 1 |
| PCS-718 L1 | 19" Shelf | 2 |
| PCS-718 L2 | 19" Shelf, Wire-Wrap | 2 |
| PCS-822 L1B | Cabinetized Field Shelf | 3 |
| Management Options | | |
| AMU-912 L1 | Management Unit | |
| T1 Multiplexer Options | | |
| PMX-744 L1B | 8-Port DS1 Multiplexer | |
| Line Unit Options | | |
| PLL-735 L2 | Dual PG-Plus Line Unit (deploys two 4-ch or 6-ch RTs) | |
| FLL-814 L1A/L1B | PG-Flex Line Unit (deploys one PG-Flex Remote Terminal) | |
| FPR-806 L1 | 6-port RPOTS | |
| 1. PCS-719 with 16 LU slots has 96-channel POTS capacity 2. PCS-718 shelf with 12 LU slots has 72-channel POTS capacity 3. PCS-822 outdoor cabinetized field shelf with eight LU slots has 48-channel POTS capacity | | |

SUBSCRIBER DROP TESTS

The FPR-806 provides the interface to initiate a subscriber drop test on the corresponding six subscriber tip and ring pairs located at the remote terminal. Simultaneous testing of multiple tip and ring pairs is not supported. Tests performed are detailed in [Table 2](#).



The tests outlined in [Table 2](#) can be initiated through MLT, craft screens or integrated TR-08 channel test, depending upon application.

Table 2. DC Resistive Signatures

| Test | Failure Condition | TR (kΩ) | TG, RG (kΩ) |
|-----------------------------|--|----------------|--------------------|
| Foreign Voltage on Drop | TG or RG > 10 Vrms TG or RG > 6 Vdc | 27.8 | 90.9 |
| All Tests OK | No failures detected | 38.3 | 90.9 |
| Ringer Test | REN > 5.0 or REN < 0.2 | 48.3 | 90.9 |
| Resistive Fault on Drop | TG, RG, or TR ≥ 150 kΩ | 58.0 | 90.9 |
| Receiver Off-Hook | Phone is off-hook | 68.0 | 90.9 |
| Hazardous Potential on Drop | TG or RG > 50 Vrms TG or RG > 135 Vdc | 78.5 | 90.9 |



The resistive signatures on the AMU-912 are biased to -14 Vdc.

SPECIFICATIONS

Table 3 lists the specifications for the FPR-806.

Table 3. Specifications

| Category | Item | Value |
|---------------------|---|--|
| Electrical | Input Voltage | -42.5 Vdc to -56.5 Vdc |
| | Input Power | Less than 40 W with four lines Off Hook and two lines ringing 5 REN each |
| POTS Specifications | RT Supervisory Range | 820 Ω plus 430 Ω for handset; or 9.6 kft on 26 AWG; 15.6 kft on 24 AWG; 25.1 kft on 22 AWG |
| | Detection of Loop Open | ≥ 10 k Ω |
| | Idle State Voltage | -48 V minimum |
| | Loop Current | 23 mA minimum |
| | Ring Generation | Unbalanced Trapezoidal 40 Vrms minimum @ 20 \pm 3 Hz up to 5 REN per line (10 REN total) |
| | Ring Trip | ≤ 200 ms after Loop Closure |
| POTS Interface | Supports Loop Start/Ground Start (LS/GS) POTS | |
| Environmental | Elevation | -200 ft. to 13,000 ft. -60 m to 4,000 m |
| | Temperature | -40° F to +150° F -40° C to +65° C |
| | Humidity | 5% to 95% (non-condensing) |
| Compliance | NEBS | SR-3580 Level 3 |
| | ESD | Per GR-1089-CORE |
| | Power Cross and Lightning Surge | Per GR-1089-CORE |
| | Human Safety | UL-1950 for Restricted Access |
| | Emissions Radiation and Immunity | GR-1089-CORE for Class A equipment |
| Physical | Height | 5.5 in. (14.0 cm.) |
| | Width | 1.1 in. (2.8 cm.) |
| | Depth | 10.25 in. (26.0 cm.) |
| | Weight | 0.6 lbs. (0.27 kg.) |

FRONT PANEL

Figure 4 shows the FPR-806 front panel and Table 4 on page 8 lists the LEDs and LED status for the FPR-806. Refer to Table 5 on page 8 for diagnostic indications.




Figure 4. FPR-806 Front Panel

Table 4. FPR-806 Front Panel LEDs

| LED | Color | State | Description |
|----------------------|--------|--------------------|--|
| PWR | Green | On | FPR-806 is receiving power |
| | | Off | FPR-806 is NOT receiving power |
| TEST | Yellow | Flashing | Subscriber Drop Testing is in progress |
| | | Off | No Subscriber Drop Testing in progress |
| FAULT | Red | On | Fault in the FPR-806 |
| | | Flashing | PMX-744 is removed |
| | | Off | No fault is detected |
| POTS# (# = 1 – 6) | Green | On | Off Hook |
| | | Ring Cadence Flash | Channel is ringing |
| | | Slow Flash | Channel is in test |
| | | Off | Channel is idle |

Table 5. FPR-806 Diagnostic Indicators

| LED State | Description | Action |
|---|---------------------------------|--|
| PWR LED On, All other LEDs flashing | FPR-806 is running in Boot Mode | Application software must be re-installed. Contact Product Support on page 45 for additional information. |
| PWR LED On, All other LEDs sequencing downward | Software download to FPR-806 | Wait for download to complete and FPR-806 to re-start |
| FAULT On, All other LEDs Off | FPR-806 hardware failure | Replace FPR-806 |

INSTALLATION AND TEST



STATIC SENSITIVE DEVICE – DO NOT HANDLE ANY MATERIAL WITHOUT FIRST TAKING PROPER STATIC CONTROL PRECAUTIONS.

REQUIRED TOOLS AND TEST EQUIPMENT

No tools are required to install the FPR-806. For testing, the following tools may be used:

- Telephone test set
- PSU-795 List 1 COTS Continuity Test Card (Optional – Streaker Card)

You can install the FPR-806 in any slot except the three positions labeled COMMON, MUX 1, and MUX 2. Refer to the cabling tables provided in the COTS documentation for slot and Telco cabling assignment.

INSTALLATION

Install an FPR-806

| Step | Action |
|------|--|
| 1 | Open the retaining latch on the front of the FPR-806. |
| 2 | Insert the FPR-806 into a vacant slot in the shelf that corresponds to the location of the wiring for the service being activated. |
| 3 | Engage the retaining latch to hold the card in place. |

INITIALIZE AND POWER UP THE FPR-806

After installing the FPR-806, the following events occur:

- All LEDs briefly blink on and then off, with the exception of the PWR LED that remains On.

ADMINISTRATION

Refer to the proper Management Unit Technical Practice for detailed Administration instructions.

For example:

1. Provision your PC/Laptop running Windows HyperTerminal or PROCOMM, etc. to the following terminal settings:

8 data bits
1 stop bit
no parity
VT-100 emulation
baud rate – 1200, 2400, 4800, 9600, 19200, 38400, 57600

2. Connect the DB-9 cable between the RS-232 port on the front of the Management Unit and the PC/Laptop serial port.

3. Press **ENTER** several times until the Main Menu appears.

NAVIGATIONAL METHODS

Table 6 shows the keys used to navigate through the menus and screens.

Table 6. Navigational Keystrokes

| Keypress | Effect on Menu | Effect on Screen |
|-----------------------------|---|---|
| ENTER | Moves to sub-menu or screen selected | Confirms changes |
| ← or CTRL - F | Moves left across Main Menu | Moves the cursor left |
| → or CTRL - G | Moves right across Main Menu | Moves the cursor to the right |
| ↑ or CTRL - T | Moves up the sub-menu selection | Moves the cursor up |
| ↓ or CTRL - V | Moves down the sub-menu selection | Moves the cursor down |
| TAB | No effect | Moves to the next field |
| SPACEBAR | No effect | Cycle through the field options |
| ESC | Moves up a menu level. From the Main Menu, the Logout screen is displayed. | Returns to Main Menu without accepting changes. The banner briefly appears and then the Main Menu bar displays. |
| CTRL - R | Returns to the Main Menu. The banner briefly appears and then the Main Menu bar displays. | Returns to Main Menu without accepting changes |
| A - Z keys | Selects an underlined or highlighted menu item | A screen entry is made |



Some screens illustrated in this document may be slightly different than what may appear on the craft interface terminal. These differences are related to individual software installations.

PROVISIONING, TESTING AND MAINTENANCE

The following sections describe how to navigate the VT-100 screens to configure, check the status of, and maintain the FPR-806 system. All configurable options are set to factory defaults to minimize field provisioning. Use the Craft terminal to verify system performance and to customize the units to your requirements.

MENUS AND DISPLAY STRUCTURE

Figure 5 shows the menu structure of the terminal management system.




Figure 5. Terminal Menu and Display Structure

Log On the FPR-806 Through the Management Unit (AMU-912)

This screen logs the user into the system. This procedure shows how to log into the FPR-806 through the AMU-912.




The factory-default password is **password#1**.

If the password has been changed and the new password is not known, contact ADC Technical Support while at the terminal. Technical Support will provide a temporary password based on the Access Key number displayed on the Logon screen.



Log On the FPR-806 Through the Management Unit (AMU-912)

| Step | Action |
|------|--|
| 1 | <p>Press SPACEBAR several times to activate the Autobaud feature. When the Login screen displays, type the <i>Password</i>, then press ENTER.</p> <div data-bbox="479 751 1239 1228" style="border: 1px solid black; padding: 10px; text-align: center;"> </div> |
| 2 | <p>If an invalid Password is entered, the Login screen is redisplayed with the message <i>Invalid Password... Try Again:</i>. Type the <i>Password</i>, then press ENTER.</p> <div data-bbox="479 1360 1239 1837" style="border: 1px solid black; padding: 10px; text-align: center;"> </div> |

Log On the FPR-806 Through the Management Unit (AMU-912) (Continued)

| Step | Action |
|------|--|
| 3 | <p>After a successful login, the welcome banner screen appears for a few seconds.</p> <div data-bbox="479 390 1239 863" style="border: 1px solid black; text-align: center; padding: 50px;"></div> <p>Then the AMU-912 Main Menu screen appears.</p> <div data-bbox="479 926 1239 1398" style="border: 1px solid black; padding: 10px;"><pre>PG-FlexPlus Management Unit MAIN NETWORK SELECT ALARMS CONFIG S/W DNLD INFO 09/26/2002 Shelf ID: NE0020A7351002 01:30:36</pre></div> |



Log On the FPR-806 Through the Management Unit (AMU-912) (Continued)

| Step | Action |
|------|--|
| 4 | <p>At the Main Menu, choose SELECT. Press ↓ to choose the appropriate <i>COLU#</i> (e.g., COLU 1).</p>  <p>The FPR-806 Main Menu appears.</p>  |



Logout

This action logs the user out of the system.

Logout

| Step | Action |
|------|---|
| 1 | <p>CAUTION <i>If you must leave your VT-100 terminal unattended for any length of time, log off until you are ready to resume work. This prevents unauthorized persons from inadvertently changing any of your operating parameters and/or experiencing loss of service.</i></p> <p>At the FPR-806 Main Menu screen, press ESC. The MU Main Menu appears.</p>  |
| 2 | <p>At the MU Main Menu screen, select MAIN. Press ↓ to choose Logout. The following screen appears.</p>  |

Logout (Continued)

| Step | Action |
|------|---|
| 3 | <p>Press ENTER. The following screen appears.</p>  <p>The screenshot shows a terminal window titled "PG-FlexPlus Management Unit". At the top, there is a menu with options: MAIN, NETWORK, SELECT, ALARMS, CONFIG, S/W DNLD, and INFO. The "Logout" option is highlighted. Below the menu, the text reads "Current Session will be Logged Out. Continue (Y/N)?". At the bottom of the screen, there is a status bar with the date "03/26/2002", the Shelf ID "NE0020A7351002", and the time "01:44:28".</p> |
| 4 | <p>Press Y. The PG-Flex^{Plus} Login screen reappears.</p>  <p>The screenshot shows a terminal window titled "PG-FlexPlus Login Screen". It prompts the user to "Enter Password:" followed by a series of black boxes representing masked characters. Below the password prompt, it displays the "Access Key: 052872232642".</p> |

MAIN MENU OPTIONS

The Main Menu provides access to the status of the system.



MAIN

The screen provides access to the status of the system.

MAIN

| Step | Action |
|------|--|
| 1 | <p>At the Main Menu screen, select MAIN. The following screen appears.</p> <div data-bbox="464 527 1252 1045" style="border: 1px solid black; padding: 10px; margin: 10px auto; width: fit-content;"> <pre> PG-FlexPlus RPOTS Line Unit #3 MAIN ALARMS CONFIG TEST INFO Channel Status IDLE-6S UUG1 -- COLU -- PRESENT IDLE-6S UUG2 -- -- PRESENT IDLE-6S UUG3 -- -- PRESENT IDLE-6S UUG4 -- -- PRESENT IDLE-6S UUG5 -- -- PRESENT IDLE-6S UUG6 -- -- PRESENT ----- ALARMS ----- SYSTEM : NONE 01/02/2000 System ID: Billis RPOTS 05:31:57 </pre> </div> |
| 2 | Press ESC . The Main Menu screen reappears. |

ALARM MENU OPTIONS

The Alarm Menu provides access to the alarm status and system related alarm events. Refer to [Table 7](#) for the sub-menu option and description, parameter and valid value.




Table 7. Alarm Menu Options

| Sub-Menu Options | Sub-Menu Descriptions | Selectable Parameter Options | Valid Values |
|------------------|---|--|---|
| System History | View the system's active critical, major and minor alarms | <ul style="list-style-type: none"> • Clear System Alarm History (Y)? • System Alarm History Will Be Cleared. Continue (Y/N)? | <ul style="list-style-type: none"> • Y • Y or N |

ALARMS — System History

This screen displays the system's active critical, major, and minor alarms.

ALARMS — System History

| Step | Action |
|------|---|
| 1 | <p>At the Main Menu screen, select ALARMS. Press ↓ to choose System History. The following screen appears.</p>  |

ALARMS — System History (Continued)

| Step | Action |
|------|--|
| 2 | <p>Press ENTER. The following screen appears.</p> <p>To clear the system history, press Y at the CLEAR SYSTEM ALARM HISTORY (Y) ? prompt.</p> <div data-bbox="477 447 1239 919" style="border: 1px solid black; padding: 5px; margin: 10px 0;"> <pre> PG-FlexPlus APOTS Line Unit #1 MAIN ALARMS CONFIG TEST INFO System History ALARMS MUX Parity Error (PARITYERR) MN OK 0 --/-- --:-- --/-- --:-- EEPROM Failure (BKUPMEMP) MN OK 0 --/-- --:-- --/-- --:-- Inv Signal Type (INUSIGNAL) MN OK 0 --/-- --:-- --/-- --:-- CLEAR SYSTEM ALARM HISTORY (Y) ? █ SYSTEM ALARM HISTORY LAST CLEARED: --/--/---- --:--:-- 11/14/2002 System 10: PG-FlexPlus System 14:51:43 </pre> </div> <p>If you want to retain the system history, press ESC. The Main Menu screen reappears.</p> <p>The alarm information displayed indicates:</p> <p>Alarm Types:</p> <ul style="list-style-type: none"> • CRITICAL Critical alarm is present • MAJOR Major alarm is present • MINOR Minor alarm is present • NOT ALARMED Condition is active, but has no severity • NOT REPORTED Condition not reported by system <p>Alarm States:</p> <ul style="list-style-type: none"> • Active Designates active alarm • OK Designates no alarm exists |

ALARMS — System History (Continued)

| Step | Action |
|------|--|
| 3 | <p>To verify you want to clear the system history, press Y at the SYSTEM ALARM HISTORY WILL BE CLEARED. CONTINUE (Y/N)? prompt.</p> <div data-bbox="479 430 1242 903" style="border: 1px solid black; padding: 5px;"> <pre> PG-FlexPlus APOTS Line Unit #1 MAIN ALARMS CONFIG TEST INFO System History ALARMS MUX Parity Error (PARITYERR) MN OK 0 --/-- --:-- --/-- --:-- EEPROM Failure (BKUPMEM) MN OK 0 --/-- --:-- --/-- --:-- Inv Signal Type (INUSIGNAL) MN OK 0 --/-- --:-- --/-- --:-- SYSTEM ALARM HISTORY WILL BE CLEARED. CONTINUE (Y/N)? █ SYSTEM ALARM HISTORY LAST CLEARED: --/-- --:-- --:--:-- 11/14/2002 System ID: PG-FlexPlus System 14:52:08 </pre> </div> <div data-bbox="479 934 1242 1407" style="border: 1px solid black; padding: 5px;"> <pre> PG-FlexPlus APOTS Line Unit #1 MAIN ALARMS CONFIG TEST INFO System History ALARMS MUX Parity Error (PARITYERR) MN OK 0 --/-- --:-- --/-- --:-- EEPROM Failure (BKUPMEM) MN OK 0 --/-- --:-- --/-- --:-- Inv Signal Type (INUSIGNAL) MN OK 0 --/-- --:-- --/-- --:-- CLEAR SYSTEM ALARM HISTORY (Y)? █ SYSTEM ALARM HISTORY LAST CLEARED: 11/14/2002 14:52:30 11/14/2002 System ID: PG-FlexPlus System 14:52:32 </pre> </div> <p>If you want to retain the system history, press N, then press ESC. The Main Menu screen reappears.</p> |
| 4 | <p>Press ESC. The Main Menu screen reappears.</p> |

CONFIGURATION MENU OPTIONS

The Configuration Menu provides access to system provisioning and setting all options to factory defaults, etc. Refer to [Table 8](#) for sub-menu options and descriptions, parameters and valid values.





Table 8. Configuration Menu Options

| Sub-Menu Options | Sub-Menu Descriptions | Parameters | Valid Values |
|--|--|--|---|
| System Options (Table 9 on page 26 for Shelf Options) | Set system options | System Options will be changed. Continue (Y/N)? | Y or N |
| System Alarm Types (See Table 11 on page 29) | Provision all FPR-806 alarm types | System Alarm Types will be changed. Continue (Y/N)? | Y or N |
| Set Factory Defaults | Reset the provisionable items to the original factory settings | <ul style="list-style-type: none"> Configuration data will be set to factory defaults (This May Be Service Affecting!) Continue (Y/N)? Configuration data has been set to factory defaults. Press ESC to continue: | <ul style="list-style-type: none"> Y or N ESC |

CONFIG — System Options

The System Options screen allows provisioning of system options. Refer to [Table 9 on page 26](#) for Shelf Options.

CONFIG — System Options

| Step | Action |
|------|---|
| 1 | <p>At the Main Menu screen, select CONFIG. Press ↓ to choose System Options. The following screen appears.</p>  <p>The screenshot shows a terminal window with a menu. At the top, it says 'PG-FlexPlus RPOTS Line Unit #1'. Below that are four menu items: 'MAIN', 'ALARMS', 'CONFIG', and 'TEST INFO'. 'CONFIG' is highlighted. A sub-menu is displayed over 'CONFIG' with three options: 'System Options', 'System Alarm Types', and 'Set Factory Defaults'. 'System Options' is highlighted. At the bottom of the terminal, it shows the date '11/14/2002', the system ID 'System ID: PG-FlexPlus System', and the time '14:52:54'.</p> |
| 2 | <p>Press ENTER. The following screen appears. To change a field value, press SPACEBAR to toggle to the desired value, or press ↓ or ↑ to move to the next option.</p>  <p>The screenshot shows a terminal window with the title 'PG-FlexPlus RPOTS Line Unit #7'. The menu items 'MAIN', 'ALARMS', 'CONFIG', and 'TEST INFO' are shown, with 'CONFIG' highlighted. A sub-menu 'System Options' is displayed with three fields: 'POTS Ringing Frequency' set to '20 HZ' (options: 20 HZ, 25 HZ, 30 HZ, 50 HZ), 'POTS DID Mode' set to 'DISABLE' (options: DISABLE, ENABLE), and 'PG-FlexPlus System ID (24 char max):' set to 'PG-FlexPlus System'. At the bottom, there is a button labeled 'ACCEPT SYSTEM OPTION CHANGES'. The terminal footer shows the date '01/28/2003', the system ID 'System ID: PG-FlexPlus System', and the time '16:21:36'.</p> <p>To save the system options, select the ACCEPT SYSTEM OPTION CHANGES button, then press ENTER.</p> |

CONFIG — System Options (Continued)

| Step | Action |
|------|--|
| 3 | <p>From the SYSTEM OPTIONS WILL BE CHANGED. CONTINUE (Y/N)? prompt, the following actions can be taken:</p> <ul style="list-style-type: none"> To save the system options, press Y. All current values are set to desired values. <div data-bbox="467 470 1252 982" style="border: 1px solid black; padding: 5px; margin: 10px 0;"> <pre> PG-FlexPlus RPOTS Line Unit #7 MAIN ALARMS CONFIG TEST INFO System Options POTS Ringing Frequency : 20 HZ (20 HZ, 25 HZ, 30 HZ, 50 HZ) POTS DID Mode : DISABLE (DISABLE, ENABLE) PG-FlexPlus System ID (24 char max): PG-FlexPlus System ACCEPT SYSTEM OPTION CHANGES SYSTEM OPTIONS WILL BE CHANGED. CONTINUE (Y/N)? █ 01/28/2003 System ID: PG-FlexPlus System 16:22:22 </pre> </div> <div data-bbox="467 1020 1252 1533" style="border: 1px solid black; padding: 5px; margin: 10px 0;"> <pre> PG-FlexPlus RPOTS Line Unit #7 MAIN ALARMS CONFIG TEST INFO System Options POTS Ringing Frequency : 20 HZ (20 HZ, 25 HZ, 30 HZ, 50 HZ) POTS DID Mode : DISABLE (DISABLE, ENABLE) PG-FlexPlus System ID (24 char max): PG-FlexPlus System ACCEPT SYSTEM OPTION CHANGES SYSTEM OPTIONS HAVE BEEN CHANGED. 01/28/2003 System ID: PG-FlexPlus System 16:22:46 </pre> </div> <ul style="list-style-type: none"> To retain the existing values, press N. |
| 4 | <p>Press Esc. The Main Menu screen reappears.</p> |



Table 9. Shelf Options

| System Options | Value | Description | Default |
|-----------------------------------|--|--|--------------------|
| POTS Ringing Frequency | 20, 25, 30, 50 HZ | Changes frequency of ringing at the RT | 20 HZ |
| POTS DID Mode | ENABLE, DISABLE | Enables/Disables POTS Direct Inward Dialing Mode | DISABLE |
| PG-Flex ^{Plus} System ID | Up to 24 characters maximum - Can contain letters, digits or hyphens | Visible at the bottom of the screen | PG-FlexPlus System |

CONFIG — System Alarm Types

The alarm types screen allows provisioning of all FPR-806 system alarm types. Table 11 on page 29 shows the alarm fields, values, descriptions and default settings. Table 10 on page 29 provides a description of the Alarm types reported.

CONFIG — System Alarm Types

| Step | Action | | | | | | | | | | | | |
|---------------------------------|--|----------------------|--|------|-------------------------------|----|----------------------|----------------------------|----|----------------------|---------------------------------|----|----------------------|
| 1 | <p>At the Main Menu screen, select CONFIG. Press ↓ to choose System Alarm Types. The following screen appears.</p>  <p>The screenshot shows a terminal window with the title 'PG-FlexPlus RPOTS Line Unit #1'. The menu options are: MAIN, ALARMS, CONFIG, TEST, INFO. 'CONFIG' is highlighted, and a sub-menu is displayed with options: System Options, System Alarm Types (highlighted), and Set Factory Defaults. The status bar at the bottom shows the date '11/14/2002', 'System ID: PG-FlexPlus System', and the time '14:54:34'.</p> | | | | | | | | | | | | |
| 2 | <p>Press ENTER. The following screen appears.</p>  <p>The screenshot shows the 'System Alarm Types' configuration screen. At the top, the title is 'PG-FlexPlus RPOTS Line Unit #1' and the menu options are MAIN, ALARMS, CONFIG, TEST, INFO. 'CONFIG' is highlighted, and 'System Alarm Types' is selected. The screen displays a table of system alarms:</p> <table border="1"> <thead> <tr> <th colspan="2">SYSTEM ALARMS</th> <th>TYPE</th> </tr> </thead> <tbody> <tr> <td>MUX Parity Error (PARITYERR):</td> <td>MN</td> <td>(NR, NA, MN, MJ, CR)</td> </tr> <tr> <td>EEPROM Failure (BKUPMEMP):</td> <td>MN</td> <td>(NR, NA, MN, MJ, CR)</td> </tr> <tr> <td>Inv Signaling Type (INUSIGNAL):</td> <td>MN</td> <td>(NR, NA, MN, MJ, CR)</td> </tr> </tbody> </table> <p>Below the table, there is a legend: [MN = Minor Alarm, MJ = Major Alarm, CR = Critical Alarm] and [NA = Not Alarmed, NR = Not Reported]. At the bottom of the screen, there is a button labeled 'ACCEPT SYSTEM ALARM TYPE CHANGES'. The status bar at the bottom shows the date '11/14/2002', 'System ID: PG-FlexPlus System', and the time '14:55:10'.</p> | SYSTEM ALARMS | | TYPE | MUX Parity Error (PARITYERR): | MN | (NR, NA, MN, MJ, CR) | EEPROM Failure (BKUPMEMP): | MN | (NR, NA, MN, MJ, CR) | Inv Signaling Type (INUSIGNAL): | MN | (NR, NA, MN, MJ, CR) |
| SYSTEM ALARMS | | TYPE | | | | | | | | | | | |
| MUX Parity Error (PARITYERR): | MN | (NR, NA, MN, MJ, CR) | | | | | | | | | | | |
| EEPROM Failure (BKUPMEMP): | MN | (NR, NA, MN, MJ, CR) | | | | | | | | | | | |
| Inv Signaling Type (INUSIGNAL): | MN | (NR, NA, MN, MJ, CR) | | | | | | | | | | | |

CONFIG — System Alarm Types (Continued)

| Step | Action |
|------|---|
| 3 | <p>The following actions can be taken:</p> <ol style="list-style-type: none"> To change the field value, press SPACEBAR to toggle to the desired value, or press ↓ or ↑ to move to the next option. To save the alarm type changes, select the ACCEPT SYSTEM ALARM TYPE CHANGES button, then press ENTER. From the SYSTEM ALARM TYPES WILL BE CHANGED. CONTINUE (Y/N)? prompt, the following actions can be taken: <ul style="list-style-type: none"> To save the alarm type changes, press Y. All current values are set to desired values. <div style="border: 1px solid black; padding: 5px; margin: 10px 0;"> <pre> PG-FlexPlus APOTS Line Unit #1 MAIN ALARMS CONFIG TEST INFO System Alarm Types SYSTEM ALARMS MUX Parity Error (PARITYERR): MN (NR, NA, MN, MJ, CR) EEPROM Failure (BKUPMEMP): MN (NR, NA, MN, MJ, CR) Inv Signaling Type (INUSIGNAL): MN (NR, NA, MN, MJ, CR) [MN = Minor Alarm, MJ = Major Alarm, CR = Critical Alarm] [NA = Not Alarmed, NR = Not Reported] ACCEPT SYSTEM ALARM TYPE CHANGES SYSTEM ALARM TYPES WILL BE CHANGED. CONTINUE (Y/N)? █ 11/14/2002 System ID: PG-FlexPlus System 14:55:34 </pre> </div> <div style="border: 1px solid black; padding: 5px; margin: 10px 0;"> <pre> PG-FlexPlus APOTS Line Unit #1 MAIN ALARMS CONFIG TEST INFO System Alarm Types SYSTEM ALARMS MUX Parity Error (PARITYERR): MN (NR, NA, MN, MJ, CR) EEPROM Failure (BKUPMEMP): MN (NR, NA, MN, MJ, CR) Inv Signaling Type (INUSIGNAL): MN (NR, NA, MN, MJ, CR) [MN = Minor Alarm, MJ = Major Alarm, CR = Critical Alarm] [NA = Not Alarmed, NR = Not Reported] ACCEPT SYSTEM ALARM TYPE CHANGES SYSTEM ALARM TYPES HAVE BEEN CHANGED. 11/14/2002 System ID: PG-FlexPlus System 14:55:59 </pre> </div> <ul style="list-style-type: none"> To retain the existing alarm types, press N. |
| 4 | <p>Press Esc. The Main Menu screen reappears.</p> |

Table 10. Alarm Types Reported

| Settings | Alarm LED Lit | Main Shelf Summary | History Updated |
|-------------------|----------------------|---------------------------|------------------------|
| CR – Critical | Yes | Yes | Yes |
| MJ – Major | Yes | Yes | Yes |
| MN – Minor | Yes | Yes | Yes |
| NA – Not Alarmed | No | No | Yes |
| NR – Not Reported | No | No | No |



Table 11. Alarm Types

| Alarm | Value | Description | Default |
|--------------------|--------------------|---------------------------------------|----------------|
| MUX Parity Error | CR, MJ, MN, NA, NR | Parity error detected on MUX | MN |
| EEPROM Failure | CR, MJ, MN, NA, NR | Non-volatile database is corrupt | MN |
| Inv Signaling Type | CR, MJ, MN, NA, NR | FPR-806 has an invalid Signaling Type | MN |

CONFIG — Set Factory Defaults

This screen resets the configuration data back to the original factory default setting.

CONFIG — Set Factory Defaults

| Step | Action |
|------|---|
| 1 | <p>At the Main Menu screen, select CONFIG. Press ↓ to choose Set Factory Defaults. The following screen appears.</p>  <p>The screenshot shows a terminal-style interface with a title bar 'PG-FlexPlus APOTS Line Unit #1'. Below the title bar are menu options: 'MAIN', 'ALARMS', 'CONFIG', 'TEST', and 'INFO'. A sub-menu is displayed under 'CONFIG', listing 'System Options', 'System Alarm Types', and 'Set Factory Defaults', which is highlighted with a black bar. At the bottom of the screen, a status bar shows the date '11/14/2002', 'System ID: PG-FlexPlus System', and the time '14:56:25'.</p> |
| 2 | <p>Press ENTER. The following screen appears.</p>  <p>The screenshot shows the same terminal-style interface. The 'CONFIG' menu is now highlighted with a black bar, and the sub-menu is no longer visible. The main text of the screen reads: 'CONFIGURATION DATA WILL BE SET TO FACTORY DEFAULTS. CONTINUE (Y/N)? █'. The status bar at the bottom remains the same, showing '11/14/2002', 'System ID: PG-FlexPlus System', and '14:56:53'.</p> <p>CAUTION <i>Setting to Factory Defaults may cause a loss of service.</i></p> |

CONFIG — Set Factory Defaults (Continued)

| Step | Action |
|------|--|
| 3 | <p>The following actions can be taken:</p> <p>a. To reset the system options back to the original factor default settings, press ENTER. From the CONFIGURATION DATA WILL BE SET TO FACTORY DEFAULTS (THIS MAY BE SERVICE AFFECTING!) CONTINUE (Y/N)? prompt, the following actions can be taken:</p> <ul style="list-style-type: none">• To save the Factory Default changes, press Y. The following events occur:<ul style="list-style-type: none">– all current values are reset to the factory default values <div data-bbox="480 579 1240 1052" style="border: 1px solid black; padding: 10px; margin: 10px auto; width: fit-content;"><pre>PG-FlexPlus RPOTS Line Unit #1 MAIN ALARMS CONFIG TEST INFO Set Factory Defaults CONFIGURATION DATA HAS BEEN SET TO FACTORY DEFAULTS. HIT <CR> TO RESUME SCREENS. 11/14/2002 System ID: PG-FlexPlus System 14:57:20</pre></div> <ul style="list-style-type: none">• To retain the existing configuration data, press N. |
| 4 | Press ESC . The Main Menu screen reappears. |

TEST MENU OPTIONS

The Test Menu provides access to the Subscriber Drop Test Facility. Refer to [Table 12](#) for the sub-menu option and description, parameter and valid values.



If you attempting to run a second test when one test is already in progress, a flashing warning message appears. Wait a few minutes, then try to run the test again.



Table 12. Test Menu Options

| Sub-Menu Options | Sub-Menu Descriptions | Parameters | Valid Values |
|------------------|---|--|---|
| Subscriber Drop | Allows Subscriber Drop Test to be performed on a particular channel | POTS (#) Chosen for Test. **WARNING** Calls in Progress on Test Circuit will be Terminated. Continue with Test (Y/N)?: | <ul style="list-style-type: none"> • POTS1 through POTS6 • Y or N |



TEST — Subscriber Drop Test

This screen allows a subscriber drop test to be performed on a particular channel.

CAUTION

Performing a subscriber drop test on any channel interrupts service on the line under test. The remaining lines on the system remain in service.

TEST — Subscriber Drop Test

| Step | Action |
|------|--|
| 1 | <p>At the Main Menu screen, select TEST. Press ↓ to choose Subscriber Drop Test. The following screen appears.</p>  <p>The screenshot shows a terminal window with a menu. At the top, it says "PG-FlexPlus APOTS Line Unit #1". Below that, there are options: "MAIN", "ALARMS", "CONFIG", "TEST", and "INFO". The "TEST" option is highlighted, and a sub-menu is displayed with "Subscriber Drop Test" selected. At the bottom of the screen, it shows the date "11/14/2002", the system ID "System ID: PG-FlexPlus System", and the time "14:57:49".</p> |
| 2 | <p>Press ENTER. The following screen appears.</p>  <p>The screenshot shows a terminal window with the same menu as the previous step. Below the "Subscriber Drop Test" option, it says "Select circuit to test:". There are six options: "POTS1", "POTS2", "POTS3", "POTS4", "POTS5", and "POTS6". The "POTS1" option is highlighted. At the bottom of the screen, it shows the date "11/14/2002", the system ID "System ID: PG-FlexPlus System", and the time "14:58:16".</p> |

TEST — Subscriber Drop Test (Continued)

| Step | Action | | | | | | | | | | | | | | | | | | |
|---------------------|---|-----------------|-------------------|-------------|---------------------|--|--------|-----------------|--|--------|-------------------|-------------------|--------|-----------------|--------------------------------------|--------|--------------|--|------------|
| 3 | <p>The following actions can be taken:</p> <p>a. To assign the POTS circuit to test, press → or ← to select the appropriate POTS# field, then press ENTER.</p> <p>b. From the POTS# CHOSEN FOR TEST. **WARNING** CALLS IN PROGRESS ON TEST CIRCUIT WILL BE TERMINATED. CONTINUE WITH TEST (Y/N) ? prompt, the following actions can be taken:</p> <ul style="list-style-type: none"> To start the test, press Y. <div data-bbox="479 573 1239 1045" data-label="Image"> </div> <ul style="list-style-type: none"> To abort the test, press N. Then press ESC and the Main Menu reappears. | | | | | | | | | | | | | | | | | | |
| 4 | <p>Upon completion of all tests, the Subscriber Drop Test Results screen with the Subscriber Test, Failure Condition, and Test Status results is displayed. Tests are performed in the order of display.</p> <div data-bbox="479 1213 1239 1686" data-label="Image"> <thead> <tr> <th>SUBSCRIBER TEST</th> <th>FAILURE CONDITION</th> <th>TEST STATUS</th> </tr> </thead> <tbody> <tr> <td>Hazardous Potential</td> <td>T-G or R-G > 50 Urms T-G or R-G > 135 Udc</td> <td>PASSED</td> </tr> <tr> <td>Foreign Voltage</td> <td>T-G or R-G AC volt. > 10 Urms T-G or R-G DC volt. > 6 Udc</td> <td>PASSED</td> </tr> <tr> <td>Receiver Off-Hook</td> <td>Phone is Off-Hook</td> <td>PASSED</td> </tr> <tr> <td>Resistive Fault</td> <td>T-G, R-G, or T-R resist. < 150 Kohms</td> <td>FAILED</td> </tr> <tr> <td>Ringers Test</td> <td>Ringer Load across T-R > 5 REN Ringer Load across T-R < 0.1 REN</td> <td><NOT DONE></td> </tr> </tbody> </div> | SUBSCRIBER TEST | FAILURE CONDITION | TEST STATUS | Hazardous Potential | T-G or R-G > 50 Urms T-G or R-G > 135 Udc | PASSED | Foreign Voltage | T-G or R-G AC volt. > 10 Urms T-G or R-G DC volt. > 6 Udc | PASSED | Receiver Off-Hook | Phone is Off-Hook | PASSED | Resistive Fault | T-G, R-G, or T-R resist. < 150 Kohms | FAILED | Ringers Test | Ringer Load across T-R > 5 REN Ringer Load across T-R < 0.1 REN | <NOT DONE> |
| SUBSCRIBER TEST | FAILURE CONDITION | TEST STATUS | | | | | | | | | | | | | | | | | |
| Hazardous Potential | T-G or R-G > 50 Urms T-G or R-G > 135 Udc | PASSED | | | | | | | | | | | | | | | | | |
| Foreign Voltage | T-G or R-G AC volt. > 10 Urms T-G or R-G DC volt. > 6 Udc | PASSED | | | | | | | | | | | | | | | | | |
| Receiver Off-Hook | Phone is Off-Hook | PASSED | | | | | | | | | | | | | | | | | |
| Resistive Fault | T-G, R-G, or T-R resist. < 150 Kohms | FAILED | | | | | | | | | | | | | | | | | |
| Ringers Test | Ringer Load across T-R > 5 REN Ringer Load across T-R < 0.1 REN | <NOT DONE> | | | | | | | | | | | | | | | | | |

 At the bottom, the date is 11/14/2002, the system ID is PG-FlexPlus System, and the time is 15:00:23.

INFORMATION MENU OPTIONS

The Information Menu provides technical information about the system. Refer to [Table 13](#) for sub-menu options and descriptions.






Table 13. Information Menu Options

| Sub-Menu Options | Sub-Menu Descriptions | Parameters | Valid Values |
|------------------|---|--|---|
| Inventory | Displays product identification information, manufacturing data, software versions and the hardware revisions for the FPR-806 | | |
| Event Log | Displays all the FPR-806 event information about the FPR-806 | <ul style="list-style-type: none"> • Clear event log history (Y)? • Event log history will be cleared. Continue (Y/N)? | <ul style="list-style-type: none"> • Y • Y or N |
| Help | Displays product identification information, manufacturing data, software versions and the hardware revisions for the FPR-806 | | |

INFO — Inventory



This screen displays product identification information, manufacturing data, software versions and the hardware revisions for the FPR-806.

| Step | Action |
|------|---|
| 1 | <p>At the Main Menu screen, select INFO. Press ↓ to choose Inventory. The following screen appears.</p>  <p>The screenshot shows a terminal window with a menu at the top: MAIN, ALARMS, CONFIG, TEST, INFO. The INFO menu is expanded to show Inventory, Event Log, and Help. The status bar at the bottom displays the date 11/14/2002, System ID: PG-FlexPlus System, and time 15:00:50.</p> |
| 2 | <p>Press ENTER. The following screen appears.</p>  <p>The screenshot shows the Inventory screen with the following text: <pre> PG-FlexPlus APOTS Line Unit #1 MAIN ALARMS CONFIG TEST INFO Inventory COLU Model Number : FPR-806 List Number : 01 CLEI : S9C2BB0BAA Serial Number : 212925318 H/W Part Number : 150-1638-01 H/W Revision : 08 FPGA Type : FPGA FPGA Version : 22 BOOT PROGRAM S/W Program Type : APOTS BOOT S/W Version : E1.0.1.3 APPLICATION PROGRAM S/W Program Type : APOTS S/W Version : E1.0.1.6 </pre> The status bar at the bottom displays the date 11/14/2002, System ID: PG-FlexPlus System, and time 15:01:28. </p> |
| 3 | <p>Press ESC. The Main Menu screen reappears.</p> |



INFO — Event Log

This screen displays all the FPR-806 event information (an unsolicited change in state, a physical or logical device change, etc.) about the FPR-806.

INFO — Event Log



| Step | Action |
|------|---|
| 1 | <p>At the Main Menu screen, select INFO. Press ↓ to choose Event Log. The following screen appears.</p>  |
| 2 | <p>Press ENTER. The following screen appears.</p>  <ul style="list-style-type: none"> • To clear the Event Log History, press ENTER at the CLEAR EVENT LOG HISTORY (Y) ? • To retain the Event Log History, press ESC. The Main Menu screen reappears. |

INFO — Event Log (Continued)

| Step | Action |
|------|---|
| 3 | <p>The following actions can be taken:</p> <ul style="list-style-type: none"> To confirm your selection, press Y and ENTER at the EVENT LOG HISTORY WILL BE CLEARED. CONTINUE (Y/N)? prompt. The following events occur: <ol style="list-style-type: none"> All Event Log History is cleared Time and date that the registers were last cleared are updated <div style="text-align: center;">  <p>PG-FlexPlus APOTS Line Unit #1 MAIN ALARMS CONFIG TEST INFO Event Log COLU EVENT LOG No Entries</p> <p>EVENT LOG HISTORY WILL BE CLEARED. CONTINUE (Y/N)? █ EVENT LOG HISTORY LAST CLEARED: --/--/---- --:--:--</p> <p>11/14/2002 System ID: PG-FlexPlus System 15:02:40</p> </div> <div style="text-align: center;">  <p>PG-FlexPlus APOTS Line Unit #1 MAIN ALARMS CONFIG TEST INFO Event Log COLU EVENT LOG No Entries</p> <p>CLEAR EVENT LOG HISTORY (Y)? █ EVENT LOG HISTORY LAST CLEARED: 11/14/2002 15:03:02</p> <p>11/14/2002 System ID: PG-FlexPlus System 15:03:02</p> </div> <ul style="list-style-type: none"> To retain the Event Log History, press N. |
| 4 | <p>To return to the Main Menu, press ESC.</p> |

INFO — Help

This screen provides information on using the system screens and menus.

| Step | Action | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|--------------------|--|------------------------|----------------|------------------|-------|----------------------------|------------------|-------------------|-----------------------------|-----------------------|--------------------|------------------------------|------------------------|-----------------|--------------------|---------------------|-------------------|----------------------|-----------------------|-----|-----------|------------------------|-------|-----------|------------------------|--------|-----------------------|------------------|--------|----------------------|----------------------|
| 1 | <p>At the Main Menu screen, select INFO. Press ↓ to choose Help. The following screen appears.</p>  | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | <p>Press ENTER. The following screen appears.</p>  <thead> <tr> <th>Keypress</th> <th>Effect on Menu</th> <th>Effect on Screen</th> </tr> </thead> <tbody> <tr> <td>ENTER</td> <td>Moves to submenu or screen</td> <td>Confirms changes</td> </tr> <tr> <td>LEFT ARROW/CTRL-F</td> <td>Moves LEFT across main menu</td> <td>Moves the cursor LEFT</td> </tr> <tr> <td>RIGHT ARROW/CTRL-G</td> <td>Moves RIGHT across main menu</td> <td>Moves the cursor RIGHT</td> </tr> <tr> <td>UP ARROW/CTRL-T</td> <td>Moves UP a submenu</td> <td>Moves the cursor UP</td> </tr> <tr> <td>DOWN ARROW/CTRL-U</td> <td>Moves DOWN a submenu</td> <td>Moves the cursor DOWN</td> </tr> <tr> <td>TAB</td> <td>No effect</td> <td>Toggle between columns</td> </tr> <tr> <td>SPACE</td> <td>No effect</td> <td>Cycles through choices</td> </tr> <tr> <td>ESCAPE</td> <td>Moves up a menu level</td> <td>Returns to menus</td> </tr> <tr> <td>CTRL-R</td> <td>Returns to Main Menu</td> <td>Returns to Main Menu</td> </tr> </tbody> | Keypress | Effect on Menu | Effect on Screen | ENTER | Moves to submenu or screen | Confirms changes | LEFT ARROW/CTRL-F | Moves LEFT across main menu | Moves the cursor LEFT | RIGHT ARROW/CTRL-G | Moves RIGHT across main menu | Moves the cursor RIGHT | UP ARROW/CTRL-T | Moves UP a submenu | Moves the cursor UP | DOWN ARROW/CTRL-U | Moves DOWN a submenu | Moves the cursor DOWN | TAB | No effect | Toggle between columns | SPACE | No effect | Cycles through choices | ESCAPE | Moves up a menu level | Returns to menus | CTRL-R | Returns to Main Menu | Returns to Main Menu |
| Keypress | Effect on Menu | Effect on Screen | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ENTER | Moves to submenu or screen | Confirms changes | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| LEFT ARROW/CTRL-F | Moves LEFT across main menu | Moves the cursor LEFT | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| RIGHT ARROW/CTRL-G | Moves RIGHT across main menu | Moves the cursor RIGHT | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| UP ARROW/CTRL-T | Moves UP a submenu | Moves the cursor UP | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| DOWN ARROW/CTRL-U | Moves DOWN a submenu | Moves the cursor DOWN | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| TAB | No effect | Toggle between columns | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SPACE | No effect | Cycles through choices | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ESCAPE | Moves up a menu level | Returns to menus | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| CTRL-R | Returns to Main Menu | Returns to Main Menu | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

 The bottom status bar shows the date '11/14/2002', 'System ID: PG-FlexPlus System', and the time '15:03:52'." data-bbox="295 495 763 721"/>

| 3 | Press **ESC**. The Main Menu screen reappears. |

FAULT ISOLATION AND TROUBLESHOOTING

Table 14 provides fault isolation and troubleshooting procedures for the FPR-806.

Table 14. Fault Isolation and Troubleshooting

| LED | State | Probable Cause | Solution |
|-------|----------|---|--|
| PWR | On | OK | |
| | Off | <ul style="list-style-type: none"> • No input power • Shelf power fuse blown • FPR-806 processor stopped | <ul style="list-style-type: none"> • Verify fuses on bay fuse panel • Check input power on the COT Shelf battery terminations • Remove and re-insert FPR-806 • Replace the FPR-806 |
| FAULT | On | Problem with the FPR-806 | Replace the FPR-806 |
| | Flashing | PMX-744 card missing from shelf | Make sure PMX-744 is installed |
| | Off | OK | |

SUBSCRIBER REPORTED FAULTS

The following sections provide procedures for isolating faults based on subscriber reports. [Table 15](#) provides subscriber fault isolation procedures for the system. At the CO, you can use the Craft interface to initiate a Subscriber Drop Test (SDT) to help determine the cause of any of the following problems: Hazardous Potential, Foreign Voltage, Resistive Fault, Receiver Off-hook, and Ringer Tests.

Table 15. Subscriber Fault Isolating

| Indicator | Probable Cause | Solution |
|--------------------------|--|---|
| No dialtone, cannot dial | Short-circuit or open-circuit | <p>At the CO using the Craft interface, select the TEST menu option and view the test results. The tests run are for Hazardous Potential, Foreign Voltage, Resistive Fault, and CPE Termination.</p> <p>If dialtone is not present, drop the channel to the Maintenance Unit (MU) Voice Frequency (VF) interface and check for dialtone:</p> <ol style="list-style-type: none"> At the Craft Terminal (from the MU Menu), select the MAIN option and press RETURN. Select the Test Access submenu option and press RETURN. Choose the Active MUX card from the Test Access submenu and press RETURN. Select the fields for the DS1 and the Channel and type of numbers of the RT in fault. Select the Enable Test Access button and press RETURN. Check for dialtone at the VF Interface. <p>If dialtone is still not present, the problem exists within the CO.</p> |
| Phone does not ring | High-resistance short on subscriber drop | <p>At the CO using the Craft interface, go to the FPR-806 Main Menu and choose MAIN on page 18 to verify the correct operation of the FPR-806. If you cannot view the FPR-806 Main Menu, a communication error exists indicating a faulty card. Remove and reinsert the FPR-806. Then replace the FPR-806, if needed.</p> <p>Go to the Test Menu Option and select the desired circuit to test. View the SDT results. Refer to the Test Submenu section for specific results.</p> <p>If ringing is not present, drop the channel to the MU interface and check for ringing:</p> <ol style="list-style-type: none"> At the Craft Terminal (from the MU Menu), select the MAIN option and press RETURN. Select the Test Access submenu option and press RETURN. Choose the Active MUX card from the Test Access submenu and press RETURN. Select the fields for the DS1 and the Channel and type of numbers of the RT in fault. Select the Enable Test Access button and press RETURN. Connect a telephone set at the CO to check for ringing. |

| Indicator | Probable Cause | Solution |
|------------------------------|---|---|
| Phone does not stop ringing | Faulty subscriber station instrument or loop length too long | <p>If phone stops ringing when using a butt-in set at the subscriber location, the subscriber's station internal resistance is too high. Replace phone.</p> <p>If phone does not stop ringing when using a butt-in set at the subscriber location, one or both of these conditions exist:</p> <ul style="list-style-type: none"> • loop length is too long (see Table 3 on page 6 for Specifications) • Replace the FPR-806 |
| Cannot hear, cannot be heard | Subscriber problem (e.g., Bad voice path in the FPC-806 card) | <p>If audible level is too low at protector drop lifted, drop the channel to the MU interface and check for voice quality.</p> <ol style="list-style-type: none"> a. At the Craft Terminal (from the MU Menu), select the MAIN option and press RETURN. b. Select the Test Access submenu option and press RETURN. c. Choose the Active MUX card from the Test Access submenu and press RETURN. d. Select the fields for the DS1 and the Channel and type of numbers of the RT in fault. e. Select the Enable Test Access button and press RETURN. f. Connect a telephone set at the CO to check for ringing. <p>If audible level is acceptable, replace the FPR-806; otherwise, the problem is in the CO switch.</p> |



If system problems cannot be resolved after following the procedures in [Table 15](#), contact [Technical Support on page 45](#).

ACRONYMS

A

ACO – Alarm Cut-Off

AWG – American Wire Gauge

C

CO – Central Office

COT – Central Office Terminal

CPOTS – Central Office Plain Old Telephone Service (Central Office Channel Unit)

CR – Critical

D

DID – Direct Inward Dialing

DS0 – Digital Signal Level 0

DS1 – Digital Signal Level 1

DSL – Digital Subscriber Line

E

ES – Errored Seconds

ESD – Electrostatic Discharge

F

FCC – Federal Communications Commission

G

GND – Ground

I

ICB – Integrated Channel Bank

L

LCF – Loop Current Feed

LCFO – Loop Current Feed Open

LED – Light Emitting Diode

LS/GS – Loop Start/Ground Start

M

MJ – Major

MLT – Mechanized Loop Testing

MN – Minor

MU – Maintenance Unit

MUX – Multiplexer

N

NA – Not Alarmed

NEBS – Network Equipment Building System

NR – Not Reported

P

PBX – Private Branch EXchange

PGTC – Pair Gain Test Controller

POTS – Plain Old Telephone Service

R**RLCF** – Reverse Loop Current Feed**RMA** – Return Material Authorization**RPOTS** – Remote Plain Old Telephone Service (Remote Terminal Channel Unit)**RT** – RemoteTerminal**S****SES** – Severely Errored Seconds**SYNC** – Synchronization**U****UAS** – Unavailable Seconds**V****VF** – Voice Frequency

PRODUCT SUPPORT

TECHNICAL SUPPORT

Technical Assistance is available 24 hours a day, 7 days a week by the contacting Customer Service Engineering group at:

Telephone: 800.366.3891

The 800 telephone support line is toll-free in the U.S. and Canada.

Email: wsd_support@adc.com

Knowledge Base: http://adc.com/Knowledge_Base/index.jsp

Web: www.adc.com

LIMITED WARRANTY

Product warranty is determined by your service agreement. Refer to the ADC Warranty/Software Handbook for additional information, or contact your sales representative or Customer Service for details.

RETURNS

To return equipment to ADC:

1. Locate the number of the purchase order under which the equipment was purchased. To obtain a return authorization number, you need to provide the original purchase order number to ADC's Return Material Authorization (RMA) Department.
2. Call or write ADC's RMA Department to ask for an RMA number and any additional instructions. Use the telephone number, fax number or email address listed below:
 - Telephone: 800.366.3891
 - Email Address: rma@ADC.com
3. Include the following information, in writing, along with the equipment you are returning:
 - Company name and address
 - Contact name and telephone number
 - Shipping address to which ADC should return the repaired equipment
 - Original purchase order number
 - Description of the equipment that includes the model and part number of each unit being returned, as well as the number of units that you are returning.
 - Reason for the return. For example:
 - The equipment needs an ECO/ECN upgrade.
 - The equipment is defective.



If the equipment is defective, please tell us what you observed just before the equipment malfunctioned. Be as detailed in your description as possible.

If there is any other reason for returning the equipment, please let us know so we can determine how best to help you.

4. Pack the equipment in a shipping carton.

5. Write ADC's address and the RMA Number you received from the RMA Department clearly on the outside of the carton and return to:

ADC DSL Systems, Inc.
14402 Franklin Ave.
Tustin, CA 92780-7013

Attention: **RMA (Number)**



All shipments are to be returned prepaid. ADC will not accept any collect shipments.

FCC CLASS A COMPLIANCE

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the use will be required to correct the interference at his own expense.

MODIFICATIONS

The FCC requires the user to be notified that any changes or modifications made to this device that are not expressly approved by ADC voids the user's warranty.

All wiring external to the product(s) should follow the provisions of the current edition of the National Electrical Code.

World Headquarters:

ADC Telecommunications, Inc.
12501 Whitewater Drive
Minnetonka, Minnesota USA 55343

For Technical Assistance:

800.366.3891



1251815
